


Commissioning Manual

1 Complete OCPP Charger ID Setup on the Fractal Platform

***Note:** This ID will be used as the **Station Serial Number** in later steps.




2 Connect FractalEV 48A, 80A EVSE to Noodoe OCPP URL (wss://ocpp.noodoe.com) Before EV OS Commissioning

3 Attach the Station Label Sticker(S) as Shown Below



Step 3


Verify that the 7-digit auto-populated Station ID matches the 7 digits on the Station ID stickers.



Step 4


Select the appropriate charger specifications:

- Output Details:
11.5kW, 1 output
19.2kW, 1 output
- Connector Type:
Type 1 (J-1772)



Step 5

Enter the Station Serial Number (SN) that you configured in 1.




4 Noodoe EV OS Commissioning

Step 1

Scan the QR code to access the Installer Panel and initiate the charging station commissioning process.

Step 2

Input the Project Code provided by Noodoe or the charge point operator.



Commissioning is now complete. The station can be found in Noodoe EV OS.